


MASTECH® MS8233Z

DIGITAL MULTIMETER Users Manual



CONTENTS

- 1. Introduction.....1**
- 2. Safety Note.....1**
- 3. Explanation Of Controls
And Indicators.....3**
 - 3.1. Product Illustration.....3
 - 3.2. Functional Push Button.....4
 - 3.3. Display Indicators.....5
- 4. Specification.....6**
 - 4.1. General Specification.....6
 - 4.1. Electrical Specification.....7

CONTENTS

- 5. Measurement Operation.....10**
 - 5.1. DC Voltage & AC
Voltage Measurement.....10
 - 5.2. Resistance Measurement.....11
 - 5.3. Diode & Continuity Check.....12
 - 5.4. Frequency Measurement13
 - 5.5. DC/AC MA Measurement.....13
 - 5.6. DC/AC 10A Measurement.....13
 - 5.7. Temperature Measurement.....14
 - 5.8. Capacitance measurement.....14
- 6. Maintenance.....14**
 - 6.1. Replacing the Battery.....14
 - 6.2. Fuse Replacement.....15
 - 6.3. Test lead replacement.....15
 - 6.4. Cleaning and Decontamination.....15

1. Introduction

This manual is used to MS8233Z Digital Multi Meter only. This Meter is a handheld and battery operated Digital Multi Meter (DMM) with multi function. This Meter is designed to meet IEC61010-1 & CAT II 600V over voltage category and double insulation. The meter with holster that is giving the main body, though downsized, high resistance against the shock of a drop.

Protection provided by the instrument will be impaired if used in a manner not specified by the manufacturer. This operating instruction covers information on safety and caution. Please read relevant information carefully and observe all the warnings and note strictly. The DMM as general measurement tool and widely used in the school, laboratory, factory and other social field.

2. Safety Note








Warning

To avoid possible electric shock or personal injury and to avoid possible damage to the meter or to the equipment under test, adhere to the following rule:

- Do not apply more than the rated voltage, of marked on the meter, between the input terminal and grounding terminal..
- Do not apply voltage between COM and OHM terminal, in the resistance measuring state.
- Do not measure current with test lead inserted into voltage or OHM terminal.
- Do not expose the instrument to the direct sun light, extreme temperature and humidity or dew full.
- Inspect the test lead for damaged insulation or exposed metal.
- Before measuring current, check the Meter's fuses and turn off power to the circuit before connecting the meter to the circuit.

- Disconnect circuit power and discharge all high voltage capacitors before testing continuity, diode, resistance, capacitance or current.
- Hazardous voltages in the test before measurement of what is known voltage to determine that determine that the equipment is functioning correctly.


Note international Electrical Symbol.

	Note-Important safety information, refer to the instruction manual.
	Application around and removal from UNINSULATED HAZARDOUS LIVE conductors is permitted.
	Caution, possibility of electric shock
	Equipment protected throughout by double insulation or reinforced insulation.
	Earth (ground) TERMINAL
	Direct current
	Alternating current

CAT II: MEASUREMENT CATEGORY II is applicable to test and measuring circuits connected directly to utilization points (socket outlets and similar points) of the low-voltage MAINS installation.

3. Explanation Of Controls And Indicators

3.1. Meter Illustration



Exterior view

- ① LCD display
- ② “MAX” push button
- ③ “BACK LIGHT” push button
- ④ “HOLD” push button
- ⑤ “FUNC” Push button
- ⑥ Rotary Switch (Knob)
- ⑦ “VΩTemp → mAµA ” Input terminal
- ⑧ “COM” input terminal
- ⑨ “10A” input terminal

3.2. Functional Push Button

Push button	Function
Func	“ FUNC ” key is the function select key that acts with trigger. Use the key as switch of DC/AC current, Diode/Continuity and °C/°F.
HOLD	Press “ HOLD ” to enter and exit the hold mode in any mode. That act with trigger.
Hz%	This key is act with trigger the duty function
*	This key is used control Backlight. This key is act with trigger. When press and hold the key over 2 sec, will enable Backlight. Press the key again , the backlight will disable.

3.3. Display Indicators

Number	Indicator	Meaning
1		DC voltage or current
2		AC voltage or current
3		Diode
4	MAX	Maximum value
5	HOLD	Data hold
6		Low battery indicator
7	MKΩ	Ω KΩ MΩ is unit of resistance
8	°F	The unit of temperature (°F: Fahrenheit)
9	μVA	mV, V is unit of voltage μA, mA, A is unit of current
10	—	Indicate negative reading
11	Hz	Frequency Unit
12	nF, μF	Capacitance unit




Fig. 2 LCD

4. Specification

4.1 General Specification

- Auto ranging DMM , that full scale is 4000 counts
- Display : 3 3/4 digit LCD display..
- Over load protection: Used the PTC protection circuit for Resistance, temperature and frequency measurement.
- DATA HOLD function
- Back Light
- Low battery indication
- Auto Power- OFF. : If the meter is idle for 15 minutes (idle time), the meter automatically turns the power off. After auto power-off, pushing any of the push button or changing the rotary switch can turn on the meter again.
- Operating temperature & Humidity: 0 ~ 40°C (32 ~104 °F)& < 80% RH
- Storage temperature & Humidity: -10 ~ 50°C (14 ~ 122 °F)& <70%RH
- Power supply:9V Battery(6F22 or 1604A Type)x1pc.
- Safety class: IEC 61010-1, CAT II 600V.
- Dimension (L x W x H) & Weight: 140 x 67 x 30mm, Approx. 112g

Accessory:K-type temperature probe

4.2. Electrical Specification (at 23±5°C;<75% RH)

4.2.1 DC Voltage

Range	Resolution	Accuracy
400mV	0.1mV	±(0.5% rdg + 2dgt)
4V	0.001V	
40V	0.01V	
400V	0.1V	
600V	1V	±(0.8% rdg + 2dgt)

4.2.2 AC Voltage

Range	Resolution	Accuracy
4V	0.001V	±(0.8% rdg + 3dgt)
40V	0.01V	
400V	0.1V	
600V	1V	±(1.0% rdg + 3dgt)

- Frequency response: 40~400Hz
- Average rectifier type.

4.2.3 Resistance

Range	Resolution	Accuracy
400Ω	0.1Ω	±(0.8% rdg + 2dgt)
4kΩ	0.001kΩ	
40kΩ	0.01kΩ	
400kΩ	0.1kΩ	
4MΩ	0.001MΩ	±(1.0% rdg + 2dgt)
40MΩ	0.01MΩ	

4.2.4 Diode Check

Range	Resolution	Function
➔	0.001V	Will display the forward drop voltage.

- Operating current: about 1mA
- Open circuit voltage: about 1.5V

4.2.5 Continuity

Range	Function
o)	If measured resistance less than 50±20Ω will buzzer is sounded.

- Open voltage: about 0.5V

4.2.6 DC Current

Range	Resolution	Accuracy
400μA	0.1μA	±(1% rdg + 3dgt)
4000μA	1μA	
40mA	0.01mA	
400mA	0.1mA	
10A	0.01A	

- Over Load protection: use the fuse(F400mA H 250V) at μA/mA range, and use the fuse(F 10A H 250V) at 10A range.
- Max input current: 400mA at 'mA' input terminal and 10A at '10A' input terminal.

4.2.7 AC Current [40Hz-400Hz]

Range	Resolution	Accuracy
400μA	0.1μA	±(1.2% rdg + 4dgt)
4000μA	1μA	
40mA	0.01mA	
400mA	0.1mA	
10A	0.01A	

- Over Load protection: use the fuse(F400mA H 250V) at μA/mA range, and use the fuse(F10A/250V) at 10A range.
- Max input current: 400mA at 'mA' input terminal and 10A at '10A' input terminal.
- Frequency response: 40~400Hz

4.2.8 Temperature

Fahrenheit Temperature [°F]		
Range	0°F~1800°F	
Resolution	1°F	
Accuracy	0°F ~50°F	(5% rdg + 5dgt)
	50°F ~750°F	(2% rdg + 5dgt)
	750°F ~1800°F	(3% rdg + 5dgt)

4.2.9 Frequency

Range	Accuracy
0.1Hz~10MHz	±(1.5+5)

- Sensitivity:3V

4.2.10 Duty

Range	Accuracy
1%~99%	1%

- Sensitivity:3V

4.2.11 Capacitance

Range	Resolution	Accuracy
4nF	0.001nF	±(3% rdg + 3dgt)
40nF	0.01nF	
400nF	0.1nF	
4μF	1nF	
40μF	10nF	
200μF	100nF	

5. Measurement Operation

5.1 DC & AC Voltage Measurement

WARNING

To avoid harms to you or damage to the meter from electric shock. Please do not attempt to measure voltage higher than DC/AC 1000V although readings may be obtained.

The DC voltage range are 400.0mV, 4.000V, 40.00V, 400.0V and 600V and then. The AC voltage ranges are 4.000V, 40.00V, 400.0V and 600V.

To measure DC or AC voltage:

5.4. Frequency Measurement

1. Set the rotary switch to "Hz" position.
2. Insert the red test lead into the "VΩHz" input terminal and the black test lead into the "COM" terminal.
3. Connect the test leads across with the circuit under testing. The measured value shown on the LCD display.

5.5. DC/AC μA or mA Measurement

DC Current range is 400.0μA/4000μA and 40.00mA, 400.0mA and then 10A range.

AC Current range is 400.0μA/4000μA and 40.00mA, 400.0mA and then 10A range.

1. Turn off power to the circuit. Set the rotary switch to the proper DC/AC μA or DC/AC mA position.
2. Break the current path to be tested. Connect the red test lead to the more positive side of the break and the black test lead to the more negative side of the break.
3. Turn on power to the circuit. The measured value show on the display.

5.6. DC/AC 10A Measurement

1. Insert the red test lead into the input terminal marked as "10A".
2. The measuring procedure is same as that of 5-5 section..

Note:

- For safety's sake, the measuring time for high current should be <10 second for each measurement and the interval time between two measurement should be greater than 5 minutes.
- When current measurement has been completed, disconnect the connection between the testing lead and the circuit under test.

5.7 Temperature Measurement

To measuring temperature should be use the K-type probe :


1. Set the rotary switch to the "TEMP" range. In this time, The environment temperature value displayed on the LCD.
2. Insert the K-type temperature probe.
3. The measured temperature value will be displayed on the LCD.

5.8 Capacitance measurement

1. Set the rotary switch to "capacitance" position.
2. Insert the red test lead into the "VΩHz" input terminal and the black test lead into the "COM" terminal.
3. Connect the test leads across with the circuit under testing. The measured value shown on the LCD display.

6. Maintenance

6.1 Replacing the Battery

When meter display  the battery must be replace to maintain normal operation.

- ① Disconnect and remove all test probes from any live source and meter.
- ② Open the battery cover on the bottom case by screwdriver.
- ③ Remove old battery and snap new one into battery holder

6.2 Fuse Replacement

Replacing the defective fuse should be done according to the following procedure.

- i. To avoid electrical shock, remove the test lead and any input signal before opening the bottom case.
- ii. Open the bottom case and then remove the defective fuse and insert a new fuse of the same size and rating (F400mA H250V or F10A H250V).
- iii. Replace the bottom case and reinstall all the screws.

6.3 Test lead replacement

The test lead that has been used and replaced shall comply with the requirements specified by the manufacturer in order to ensure operation safety, (1000V CAT II 10A).

6.4 Cleaning and Decontamination

The meter can be cleaned with soft clean cloth to remove any oil, grease or grime. Do not use liquid solvent or detergent.

