

# Features:


## 1. Automatic Signal Transmission



## 2. Automatic Group Synchronization

Remarks:

1. " Synchronizing automatically
2. Different receivers can work synchronously even when started at different times. ( But should be within 30m)



## 3. Automatic Adjusting and Manual Adjusting

Static mode	<ol style="list-style-type: none"> <li>1. Any color is available on color ring.</li> <li>2. Saturation Control with W/R/G/B.</li> <li>3. White mode is available by long pressing "ON".</li> <li>4. Colors (no white) are dimmable with the slider button.</li> </ol>
Dynamic mode	<ol style="list-style-type: none"> <li>1. White light fades in and out.</li> <li>2. Several colors fade in and out.</li> <li>3. R,G,B three colors fade in and out.</li> <li>4. R,G,B three colors flash.</li> <li>5. Six colors flash.</li> <li>6. Random color flashes.</li> <li>7. Red color fades in and flashes.</li> <li>8. Green color fades in and flashes.</li> <li>9. Blue color fades in and flashes.</li> </ol> <p>Remarks: 1. Dim up or down the white color under dynamic mode with "W" button. ( Note: white color is not dimmable under Dynamic mode 1)</p>

## Specification:

Receiver  
 1. Working voltage: DC12V/24V  
 2. Output: Max. 6A/Channel (Total output Max. 10A)  
 3. Max. standby power: 0.5W  
 Remote control  
 1. Working voltage: 3V  
 2. Standby power: <math>\lt; 20\mu\text{A}</math>  
 3. Transmitting power: 6dBm

## How to link or unlink:

Link : Press Key "ON" once within 3 seconds after switching it on.  
 The link is done once the white light blinks.

Unlink: Long press Key "ON" once within 3 seconds after switching it on.  
 The unlink is done once the white light blinks.



Made in China

